



LED Stop Sign Instructions

Operation of the LED Stop Sign

- 1) Grasp the foam handle and hold the sign upward.
- 2) Press the FLASH/ON/OFF button above the handle to switch between **Flashing**, **Solid**, and **OFF** modes.
- 3) To temporarily turn off the sign, hold the sign downward (with the word “**STOP**” upside down). The LEDs will now turn off and you will be in energy saving mode.
- 4) When ready for storage, ensure the sign is powered off.

Charging Instructions

- 1) Fully charge the battery before using for the first time
- 2) To charge the battery, plug the included AC battery charger into a 120/240VAC wall outlet. Insert the round plug into the charge port in the battery, located at the bottom of the sign handle.
- 3) The LED indicator on the battery charger will **blink** red. This will indicate that the battery is being charged. A discharged battery will take approximately 3-4 hours to complete charge. When battery is fully charged, the LED will be a **steady red**. You may disconnect the charger and use the sign. On a full charge, you can expect to get over 3 hours of continuous **Solid-On** function and over 12 hours of **Flashing** function at a time.

Battery Replacement

Your LED Stop Sign is supplied with a long-lasting Lithium-ion Battery Pack, lasting approximately 500 charge cycles.

- 1) Order a replacement battery pack from SafetySign.com.
DO NOT USE ANY OTHER BATTERY.
- 2) Twist battery, located at the base of the sign handle, left and pull to remove.
- 3) Insert new battery and twist right to lock into place.

Warranty

The LED Stop Sign and accessories are subject to a 1 year warranty from date of purchase.

Contact us if you have any more questions about your LED Stop Sign!